



## **3 Year 36,000 Mile Limited Warranty**

All of Texas D.A.R Enterprises Inc. have a limited three year warranty on its products to be free of manufacturers defects from the original date of purchase (p.o.p. required). Warranty coverage is provided for paint defects, peeling, and or other paint adhesion and finish defects.

Texas D.A.R. Enterprises, Inc. will match the O.E. color of the spoilers to the factory color specifications. Factory specifications allow for a degree of variance, both lighter and darker, due to many factors. Texas D.A.R. Enterprises, Inc. cannot be responsible for this variance. With vehicles 2 years and older, we cannot be responsible for color match due to fading. Seller's and manufacturer's only obligations shall be to replace the product proven to be defective by Texas D.A.R. Enterprises, Inc.

We shall not be liable or responsible for injury, loss or damages, direct or consequential, such as improper installation, misuse, abuse, scratches, chips or fading due to neglect, or unauthorized repairs. Texas D.A.R. Enterprises, Inc. will not be responsible for any damage caused to other parts by defective product or any other costs. Failure to follow any of the instructions provided will void warranty, expressed and implied. For further information please contact us directly.

### **Installation**

#### **STEPS FOR INSTALLATION**

1. Using panel puller remove any trim-panels from underside of decklid. It is recommended to cover or remove any carpeted trunk mats or other items in trunk area to avoid damage.
2. Place plastic T-strips into mounting holes on spoiler. A small piece of masking tape is helpful in holding T-strip in position.
3. Place spoiler on closed decklid and align to proper position. A measuring tape will ensure a "perfect" alignment.
4. Using masking tape, secure T-strips to decklid of vehicle.



- Remove spoiler by lifting straight up, leaving T-strips secured to decklid.
5. Using a 1/8" drill bit, drill thru the T-strip hole and into the decklid. Remove T-strips from vehicle. If decklid contains a "double panel" Drill through inner panel also. Using a 5/16" drill bit, drill thru the 1/8" hole in step 4.
  6. If a "double panel" exists, use a 3/4" drill bit to drill thru the "inner panel". This allows the ratchet or nutdriver to secure the screw tightly against the upper panel.
  7. Place spoiler on decklid and using supplied screws and ratchet or nutdriver secure spoiler to vehicle.
  8. When installing spoilers with a L.E.D. brake light it is recommended to splice into the 3rd brake light in the vehicle and attach spoiler wires using electrical tape.
  9. Apply small amounts of silicone based caulk over spoiler screws as this will help prevent leakage, rusting, or loosening of screws.
  10. Reinstall any panels, mats or other items removed earlier in installation as noted in step 1.

#### **ASSEMBLY INSTRUCTIONS**

1. Install light by removing plastic backing on light, exposing adhesive tape. Firmly press light into groove.
2. Remove wax paper backing on neosponge gaskets, exposing the sticky adhesive.
3. Firmly press gaskets to bottom of spoiler stanchions. Make sure gaskets are centered correctly on stanchions.

#### **PAINT INSTRUCTIONS**

1. Inspect spoiler for imperfections. If filling is required use a catalyzed body filler.
2. If a catalyzed body-filler is used, be sure to prime over spot.
3. Sand spoiler with a 400 grit (or finer) wet sand paper until surface is smooth.
4. Apply basecoat/clearcoat finish of your choice.

#### ***NOTE:***

This spoiler has been coated with a catalyzed primer/sealer. Unless additional filling has been done, no primer is required.

#### ***CAUTION:***

**Do not fill, cover or obstruct vent holes in the bottom of the**

**spoiler. These holes are essential for proper ventilation of fiberglass fumes.**

***IMPORTANT:***

Please inspect your spoiler for proper fit before painting or mounting. Parts which have been sanded, painted, drilled or modified cannot be returned.

---

1001 Santerre Drive · Grand Prairie, TX 75050  
Toll Free Order Line: (800)265-9917 / Tel: (972)988-8740 / Fax: (972)602-9958  
[info@texasdar.com](mailto:info@texasdar.com)

© Copyright 2001, Texas DAR. All rights reserved.