

# Installation Instructions

Always read instructions carefully prior to installation

## Supplied In Kit

- One Piece JSP Spoiler
- One Set Pedestal Gaskets
- One Set M6 Plain Washers
- One Set Locator Strips
- LED Brake Light (If Applicable)
- One Set LED Wire Connectors

## Required Tools

- Electric Drill
- 12 Volt Battery Source
- Pilot Drill Bit 3/32" (2mm)
- 9/32" (6.5mm) Drill Bit
- Phillips Head Screwdriver
- Masking Tape
- Rust Inhibiting Primer
- Felt Tip Pen

## Led Testing Instructions (If Applicable):

Every LED has been tested by JSP Factory Technicians, therefore the possibility of an LED malfunctioning is minimal. In some rare occurrences due to factors beyond our control, the LED will fail to operate. To protect your time and investment, it is important to test the LED light before painting and installation. To test the LED, use an independent twelve (12) volt battery or charger. Touch the wires to the positive and negative terminals. If the LED does not light up simply reverse the wires.

## FITTING:

Carefully position the spoiler and find the most suitable location. Stand back and view the car from all angles. **IMPORTANT:** Before you start any installation or paint work, always read instructions prior to any installation. Make sure that the end features of the spoiler are clear of the bodywork by a minimum of 5/32" (4mm) and that the spoiler will clear the radio/telephone aerial when the trunk is opened.

## PAINTING:

The spoiler is made of durable Polymer composite or high grade ABS and finished in a high quality 2k primer. While you may use any paint for top coat spraying, we recommend 2k paint. If required, rub with Scotchbrite™ pad or wet sand with fine paper

before spraying topcoat. It is also advisable to test a small sample of paint on the underside of the spoiler to ensure that good adhesion can be obtained and that there is no attack on the spoiler.

## INSTALLATION:

1. Clean trunk lid and dry thoroughly.
2. Carefully position the spoiler and find the most suitable location. Stand back and view car from all angles. When satisfied with position, mark its position with felt tip pen.
3. Insert locator strips provided in hardware kit into mounting holes. Use small piece of masking tape to secure locator strips to spoiler. The tabs should be parallel to the spoiler.
4. Tape down the locator strips and carefully remove the spoiler leaving the locator strips taped to the trunk lid.
5. Drill pilot holes through the center of the locator strips using a 3/32" drill bit. Remove locator strips and bore out the holes using a 9/32" drill bit. Locate and drill a hole for the LED wire. (If Applicable)
6. Treat all holes with rust inhibiting fluid/primer.
7. Install gaskets onto pedestals. (Tip: Since gaskets are sticky, spray exposed gaskets with water. This will enable you to reposition the spoiler for an easier installation.)
8. Simply screw the spoiler in place with screws provided in kit, avoid over-tightening.
9. Feed the LED wire through the LED channel. (Always test light with a 12 volt battery before installing into spoiler.) All the hardware is supplied for an easy hookup to the third brake light. (If Applicable)
10. Once the wing is secure and the LED light is working (If Applicable), finish up by cleaning out the trunk lid thoroughly, making sure to remove all metal shavings.

**Toll-Free Tech Hotline: 1-800-821-0110**

## **Three Year Limited Warranty**

**All of JSP Rear Spoilers, Brush Guards and Graphic Packages carry a limited three year, from the date of purchase (proof of purchase required), warranty against manufacturer's defects. Seller's and manufacturer's only obligation shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage caused to other parts by the defective product or any other costs, i.e., removal, replacement, painting, shipping, etc. Failure to follow any of the instructions provided with the product will void warranty, expressed or implied.**