

E-Brake Handle Cover Installation

NOTE: The installation of the Billet E-Brake Handle does NOT require the removal of the existing E-Brake Handle.



1. Before installing, make sure the two allen set screws have been removed from the new billet handle.
2. With the billet button in place, slide the E-Brake Handle over top of the existing E-Brake handle until it stops.

3. Re-Insert the two allen set screws into the billet handle and tighten to secure the handle.
4. Test to verify the handle / button function properly before using the E-Brake.