

## Billet Fuel Door Installation Instructions (94-04)



Remove the factory fuel door from the vehicle by removing the four torx bit retaining screws.

Remove the two nuts and bolts from the front (side facing front of car) and guide the back end into the fuel door opening (the fuel door has two U brackets already installed...if too tight loosen these then retighten after install). Then screw in the two long bolts into the factory holes for the fuel door as shown above.



Install the two supplies nylock nuts on the back side of the two bolts holding the front of the fuel door in (pictured above).

The finished product.