

## 79-04 Mustang Billet Pedal Installation

1. Remove the factory rubber covers on the existing pedals, excluding the gas pedal and foot rest pedal. Place the new billet pedal covers over the steel pedals and mark the holes to be drilled with a marker.



2. Using a 7/64 drill bit and drill, drill pilot holes for the screws in the marked locations. Repeat for each pedal.



3. Fasten the pedal covers using the supplied stainless screws.



*Pictures shown above for 1979-2004 Mustang but installation also applies to Focus, Truck and SUV pedal kits.*