



## 94-97 Mustang Clock Pod Bezel Installation

### **Supplies:**

Rubbing alcohol  
Rag  
Clear Silicone

### **Parts:**

(1) Clock Pod Bezel

### **Estimated Time:**

5 minutes.

### **Directions:**

1. Clean the area where the bezel will be mounted with rubbing alcohol, windex can also be used to clear the area.
2. Once the mounting area is clean and dry put a thin bead of silicone on the back side (side without protective coating on it) of the bezel and press into place.
3. Hold in place to make sure it stays in place.