

UPR 03-04 Cobra Cold Air Intake System Installation



1. Disconnect the MAF Plug and remove the factory MAF Meter and air box / inlet system.



2. Once removed, detach the factory MAF meter from the factory air box assembly. *REMOVE SCREEN ASSEMBLY FROM MAF-DO NOT REINSTALL*



3. Attach the MAF Meter to the UPR Inlet Tube using the supplied stainless steel bolts and nylon lock nuts. Make sure both pieces sit flat against each other and do not over tighten.



4. Install the Stainless Steel Heat shield on the inside of the fender well using the factory air box fastening screw to hold it in place.



5. Place the UPR Big Mouth Filter in the fender well opening from underneath the car. Reinstall the MAF Meter to the factory rubber inlet tube & join the UPR Big Mouth Filter to the UPR Inlet Tube and tighten all the clamps.



6. The finished installation.