

05-09 Mustang Chrome Moly Strut Tower Brace



On the passenger side strut tower remove the 10mm nut holding the stock ground strap down.

Move the ground strap to the new location and tighten down 10mm nut



On the driver side strut tower remove the two bolt holding the bracket in place.



Line up the feet of the strut tower brace with the factory holes and install the bar in place using the provided (4) 10mm hex nuts and washers.