

## UPR Battery Mount Bracket Kit

### Assembly & Installation Instructions:

1. Remove Factory Battery Bolt & Clamp Assembly
2. Install the Threaded Rod through the factory Battery Clamp
3. Drop Upright Bar over threaded stud and fasten with flange nut. Make sure threaded rod does not protrude from upright bar. This locks down battery.
4. Assemble rear clamp to top bar with screws provided. Do not tighten yet. If using factory strap also thread it between top bar and rear clamp.
5. Center Top Bar Assembly on battery and fasten to upright bar with remaining screws. Tighten all screws.

