

79-04 Mustang UPR Oil Catch Can Installation

79-04 Mustang Assembly & Installation Instructions:

1. Determine mounting location. We recommend the passenger side strut tower or inside fender.
2. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
3. Determine your mounting location and drill a hole for the bolt to go through from inside your fender well. Make sure there are no wires or lines on the other side of your drilling location.
4. From inside the fender well use the supplied bolt and lock washer and screw it into the oil catch can mount.
5. The new routing of the hose should go from the valve cover to the oil catch can then from the other side of the catch can to the intake tube. Layout the supplied hose and cut to proper length. (Note: inlet and outlet are universal so it doesn't matter which side you use)
6. Push the hose onto the valve cover and onto one side of the oil catch can barb.
7. Push the other hose onto the other side of the oil catch can and then onto the intake tube.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE



Product Liability Statement: The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The buyer has complete responsibility for the installation, use and upkeep of this product.

Be sure to shop our online store for the best deals: www.uprproducts.com