

UPR Extreme Idler & Pulley Install (03-04 Cobra)

1. Remove the factory supercharger pulley cover from the front of the blower and engine.
2. Remove belt with 1/2 in" drive ratchet or breaker bar by installing it in the stock belt tensioner and pushing it down.
3. Slip belt off of Blower pulley and gently release pressure off the tensioner.
4. Place large black spacer into rear of bracket. Slide 8mm X 75mm bolt through both pieces.
5. Take UPR Extreme idler and place it in the slot shown in fig. 1 and gently line up the large front mount bolt and do not tighten it yet as you still need to install and line up the small top mount bolt.
6. Tighten up the large front mount bolt using a 13mm socket to tighten it. After that you can now tighten up the small top mount bolt with a 10mm socket to tighten it. Fig.2
7. Install the Extreme pulley and use the supplied button head allen wrench bolt to lock it in place by using a 6mm Allen wrench to tighten it in place. Fig. 3
8. Re-install your belt and enjoy the power increase from the added tension on your belt from the UPR Extreme Idler & Pulley kit. Fig.3

Hardware included with install kit:

1. 8mm X 75mm / Long bolt / 13mm socket to tighten
2. 10mm X 25mm / Button head allen bolt / 6mm allen wrench to tighten
3. 6mm X 40mm / Medium bolt / 10mm socket to tighten



Figure 1



Figure 2



Figure 3