



1979-2004 Mustang Extreme Pistol Grip Shift Knob Installation

Tools/Supplies:

Basic hand tools.

Parts:

- (1) Shift Handle
- (1) ¼-20 X 5/16 set screw
- (1) 1/8 allen key

Estimated Time:

5 Minutes

1. Remove factory shift knob.
2. Screw shift handle into place and tighten ¼-20 set screw in base of knob using 1/8 allen key.