



2005-2009 Mustang Extreme Pistol Grip Shift Knob Installation

Tools/Supplies:

Basic hand tools.

Parts:

- (1) Shift Handle
- (1) Delrin boot retainer
- (1) 6/32 X ¼ set screw (for boot retainer)
- (1) ¼-20 X 5/16 set screw (for shift handle)
- (1) 1/16 allen key
- (1) 1/8 allen key

Estimated Time:

5 Minutes

1. Remove factory shift knob.
2. Slide delrin boot retainer down shift handle. Slip leather boot up over lower ridge of retainer and position it into center groove. Tighten 6/32 X ¼ set screw with 1/16 allen key.
3. Screw shift handle into place and tighten ¼-20 set screw in base of knob using 1/8 allen key.