

87-04 Mustang Billet Turn Signal Knob Installation

1. Slide the new Turn Signal Knob over the plastic Turn Signal knob. Make sure the allen set screw is located on the bottom, out of view.



2. Using the supplied allen wrench, tighten the allen set screw to lock the Turn Signal Knob in place.

