

## 04-06 Pontiac GTO UPR Oil Catch Can Installation

### 04-06 Pontiac GTO Assembly & Installation Instructions:

1. Remove the factory passenger fuel rail cover.
2. At the passenger side front of the intake you will see an 11/32 hose going from the intake to the engine this is the crank case to intake vent, remove that hose.
3. Locate the bolt in the front of the passenger side cylinder head at the top, the only thing this bolt holds up is a ground wire.
4. Remove that bolt (13mm socket) from the head.
5. Connect the two 3/8" lengths of hose to each of the barbed fittings on the catch can.
6. Attach the mounting bracket to the top of the car with the provided allen head bolt.
7. Using the provided bolt mount the catch can to the front of the head with the barbs facing the engine, the round spacer goes between the bracket and cylinder head. Make sure the ground strap stays attached to the head.
8. Connect each 3/8 hose to the port on the intake and engine (the UPR can does not have an in and out so it doesn't matter which hose is connected to which port).
9. Double check your connections, level the catch can and tighten the mounting bolt.
10. Press the fuel rail cover back into place. .

### **NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE**



*Product Liability Statement: The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The buyer has complete responsibility for the installation, use and upkeep of this product.*

***Be sure to shop our online store for the best deals: [www.uprproducts.com](http://www.uprproducts.com)***