



Assemble table upside down on carpet or cardboard to protect during assembly.

Insert cam pins, cam locks, wood dowels and leveling glides into holes. Use Phillips screwdriver to fasten cam locks and pins.

Carefully turn table right side up when done, then insert deep covers.