



2010-2014 Mustang Billet Fuel Door Instructions

1. Open the factory fuel door and locate the 4 indicator marks on the fuel door bucket as shown on the attached template.
2. Using a ¼" drill bit drill holes next to each mark as shown on the template.
3. After the 4 holes are drilled the only thing holding the bucket in is the rubber grommet over the fuel filler neck and a wire connector on the right side. Disconnect that wire and remove the bucket from the car.
4. Using a 7mm socket remove the factory fuel door from the car.
5. Next snap in 3 of the nylon inserts into the body of the car directly behind where you drilled the ¼" holes leaving the bottom right hole without an insert.
6. Using the template as a guide use a razor blade and cut a notch in the outer rubber grommet on the top and the bottom where it indicates "cut".
7. Push the factory fuel door bucket back into place and screw in the provided 3 screws into the nylon inserts to hold the bucket in place.
8. Hold the door up to the fuel door bucket and mark and drill ¼" holes in the top and bottom center of the bucket as shown on the template.
9. Remove the 3 screws and pull the bucket back out.
10. Install a U-Nut at the top and bottom of the bucket where you cut the notch out earlier making sure the screw hole lines up with the hole in the bucket.
11. Push the bucket back onto the car and secure it with the 3 screws.
12. Put one of the 10/24 socket head screws through the top hole in the fuel door and place the two flat washers behind the door and thread the screw into the top hole in the bucket. Do not tighten.
13. Put the other 10/24 screw through the bottom hole in the door and into the bucket and tighten. Go back and tighten the top bolt.

Be sure to shop our online store for the best deals: www.uprproducts.com