

11-14 Mustang 5.0L TVS, Whipple, Roush Supercharged Catch Can Installation

Instructions:

1. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and O-ring to hold it in. (Inlet side is the side coming from the valve cover).
2. Screw in the pipe plug or petcock into the bottom of the can.
3. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
4. Install the bottom of the can to the top.
5. Install the 3/8 fittings into the side of the can.
6. Disconnect the vent line going from the passenger side of the supercharger down the vent tube running along the top of the passenger side valve cover. See picture below.
7. Remove the plastic push pin holding the plastic cowl cover down to the pinch weld and mount the catch can to this hole with the provided hardware.
8. On the short hose provided push the 90* OEM Ford fitting into one end.
9. Attached the other end of the short hose to the outlet side of the catch can and connect the fitting onto the side of the supercharger.
10. On the long hose provided push one end onto the inlet side of the catch can and the other end onto the fitting on the vent tube over the valve cover.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE



Be sure to shop our online store for the best deals: www.uprproducts.com