

UPR Billet Diffuser for Billet Technology Catch Can Installation

Assembly & Installation Instructions:

1. Remove BT Catch Can.
2. Unscrew BT Catch Can top.
3. Remove the screws holding the screen in place.
4. Install the UPR Catch Can Diffuser with the extended chamber going on the inlet side.
5. Re-install both screws using loc-tite to secure the UPR diffuser in BT top.
6. Screw the two pieces of the catch can back together and re-install in the vehicle.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE



Be sure to shop our online store for the best deals: www.uprproducts.com