



UPR Billet Automatic Installation

Tools:

Allen key assortment

Parts:

Shift Handle

Button

Set screw

Allen key

Est. Install Time:

15-30 minutes

Handle Directions:

1. First look at your stock handle and see if there is a set screw in the base of the handle. Some models do and some don't. If you do have one loosen the set screw.
2. Next set the parking brake.
3. Push the selector button in on the shift handle and pull it back into 1st gear. While holding the selector button in pull up on the handle and it will come loose.
4. If you have a car with the overdrive button mounted in the handle skip to the section below.
5. With the stock handle removed now put the new handle in place and the button should be sticking outside of the handle approximately a ¼" or so.
6. Now install the set screw in the side of the base of the handle and tighten to keep the handle in place.
7. Test the handle by pushing in the button and changing gears.

Overdrive Bracket Directions:

1. With the handle removed from the shifter shaft follow the wiring under the center console and disconnect at the connector. The connector is hard to get to but it can be found without having to cut the wiring.
2. Slide the relocation bracket onto the shifter shaft and secure at preferred height with the set screw provided.
3. From the top install the overdrive button wiring end first and reconnect.
4. Continue on with handle instructions step 5.