

## 79-04 Mustang UPR Oil Catch Can Installation

79-04 Mustang Assembly & Installation Instructions:

1. Determine mounting location.
2. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
3. Screw the pipe plug or petcock into the bottom of the can.
4. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and o-ring to hold it in. (Inlet side is the side coming from the valve cover).
5. Screw the two ends of the can together.
6. Mount the can to the location of your choice.
7. Route the hose from the valve cover to the inlet side of oil catch can then from the other side of the catch can to the intake tube. Layout the supplied hose and cut to proper length.
8. Push the hose onto the valve cover and onto one side of the oil catch can barb.
9. Push the other hose onto the other side of the oil catch can and then onto the intake tube.

**NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE**



*Be sure to shop our online store for the best deals: [www.uprproducts.com](http://www.uprproducts.com)*