



750 Eastcoast St South • Lake Worth, FL 33460

561-588-6630 • Fax: 561-585-4141

www.uprproducts.com

UPR Billet Depot Clothes Hanger Install

Tools/Supplies:

Phillips screwdriver or torx bit

Parts:

(2) Large clothes hangers.

(2) Aluminum spacers.

(2) Plastic inserts.

Estimated Time:

5-10 Minutes

1. Begin by removing the screw on your factory clothes hanger.
2. There are two types of mounting holes on Ford vehicles either a square hole or a small circular hole the screw went into. If you have the square hole then place one of the supplied square plastic inserts into the hole.
3. Next take the factory screw and push it through the round spacer and bolt it into the factory hole or into the hole in the plastic insert.
4. Once tightened then place the hanger over the spacer and tighten the set screw with the supplied allen key.
5. Repeat on opposite side.

Be sure to shop our online store for the best deals: www.uprproducts.com