

E-Brake Installation (79-04)

NOTE: The installation of the billet E-Brake Handle does NOT require the removal of the existing E-Brake handle.



1. Before installing, make sure the two allen set screws have been removed from the new billet handle.
2. With the billet button in place, slide the E-Brake Handle over top of the existing E-Brake handle until it stops.
3. Re-Insert the two allen set screws into the billet handle and tighten to secure the handle.
4. Test to verify the handle / button function properly before using the E-Brake.