



05-10 Pistol Grip Shift Handle Installation

Tools/Supplies:

Basic hand tools.

Parts:

(1) Shift Handle

(1) Delrin boot retainer

(1) 6/32 X ¼ set screw (for boot retainer)

(1) M12 X 1.25 jam nut

(1) 1/16 allen key

Estimated Time:

5 Minutes

1. Remove factory shift knob.
2. Slide delrin boot retainer down shift handle. Slip leather boot up over lower ridge of retainer and position it into center groove. Tighten 6/32 X ¼ set screw with 1/16 allen key.
3. Screw shift handle into place and tighten.