



Bullitt Pedal Kit Installation

Tools:

Flat head screw driver

13mm socket

Socket wrench

Hammer

Small punch

Parts:

(1) Dead Pedal

(1) Clutch Pedal

(1) Brake Pedal

(1) Gas Pedal

Estimated Time:

45 minutes.

Directions:

1. Remove the stock clutch and brake pedal covers by pulling them off the metal pedal assemblies.
2. Install the new covers in the same manner as they old ones were removed. Starting at the top and stretching the cover around the metal pedal till they fully seat. Use soap/water on the cover as a lubricant to assist in installation.

NOTE: Be careful not to damage the covers when stretching them onto the stock metal pedals.

3. Remove the stock dead pedal cover by removing the plastic clips holding them in place. A flat screw driver works the best for this.
4. Align the new dead pedal cover tabs with the holes in the dead pedal and push it into place.
5. To install the gas pedal the assembly must be removed from the car. Start by disconnecting the cable from the top of the gas pedal.
6. Next remove the two 13mm nuts holding the pedal assembly to the inside of the car.
7. With the assembly out of the car use the hammer and punch to push the metal pin holding the plastic pedal to the gas pedal assembly but do not push it out all the way just enough to be able to remove the plastic pedal.
8. Install the new pedal by doing the reverse of step 7 and push the metal pin back in to hold the new pedal assembly in place.