



750 Eastcoast St South • Lake Worth, FL 33460

561-588-6630 • Fax: 561-585-4141

www.uprproducts.com

94-97 Mustang Clock Pod Bezel Installation

Supplies:

Rubbing alcohol

Rag

Clear Silicone

Parts:

(1) Clock Pod Bezel

Estimated Time:

5 minutes.

Directions:

1. Clean the area where the bezel will be mounted with rubbing alcohol, Windex can also be used to clear the area.
2. Once the mounting area is clean and dry put a thin bead of silicone on the back side (side without protective coating on it) of the bezel and press into place.
3. Hold in place to make sure it stays in place.

Be sure to shop our online store for the best deals: www.uprproducts.com