



Cold Air Intake Kit for 2005-08 Mustang GT

- 1) Remove the stock intake from the throttle body to the airbox. There is only one bolt on the airbox.
- 2) Install heat shield using the stock airbox bolt.
- 3) Assemble the intake. Install the rubber elbow onto the pipe (Putting the long end of the elbow on the pipe).
- 4) Remove the stock MAF sensor and using supplied screws install into the billet MAF port.
- 5) Be sure air flow arrow on sensor is pointing toward the throttle body end of pipe.
- 6) Install air filter on the end of the MAF sensor.
- 7) Install the unit onto the throttle body. The filter flange will rest in the heat shield cut out.
- 8) Adjust the pipe in and out of the elbow so the filter sits just away from the body panel and the filter is sitting at its lowest point. Tighten all clamps.
- 9) Replace the factory hard line, PVC hose on the valve cover with the hose supplied.

YOU MUST TUNE YOUR CAR FOR THIS KIT. FAILURE TO DO SO WILL RESULT IN ENGINE DAMAGE.

****DO NOT DRIVE WITHOUT A TUNE!****

For all tuning questions, contact SCT tech at support@sctflash.com and their Q&A forums at www.sctflash.com/forum/index.php

Be sure to shop our online store for the best deals: www.uprproducts.com