

Billet Headlight Knob Installation



1. Pull the existing factory headlight knob out to the "ON" position. Insert a small flat headed screwdriver into the slot on the side of the headlight knob. Gently pry on the retainer clip while pulling on the knob. The knob will simply slip off the mounting post once the clip is disengaged.



2. Leave the mounting post in the "ON" position while mounting the new billet headlight knob.



3. Slide the new billet headlight knob over the mounting post. Tighten the allen set screw using the supplied allen wrench.

Billet Headlight Knob Installation



1. Pull the existing factory headlight knob out to the "ON" position. Insert a small flat headed screwdriver into the slot on the side of the headlight knob. Gently pry on the retainer clip while pulling on the knob. The knob will simply slip off the mounting post once the clip is disengaged.



2. Leave the mounting post in the "ON" position while mounting the new billet headlight knob.



3. Slide the new billet headlight knob over the mounting post. Tighten the allen set screw using the supplied allen wrench.



750 Eastcoast St South • Lake Worth, FL 33460
561-588-6630 • Fax: 561-585-4141
www.uprproducts.com
