



86-95 5.0/5.8 Mustang Race Pulley Set Installation

**Installation of these pulleys will require a shorter belt. Belt length will vary depending on your application and accessories on the vehicle.

Parts:

- (1) Alternator pulley
- (1) Water pump pulley
- (1) 3" Race crank pulley
- (4) 3/8" Socket head cap screws

Directions:

1. Disconnect negative terminal on battery.
2. Loosen the (4) water pump pulley bolts.
3. Loosen the (4) crank pulley bolts.
4. Using an impact gun break the nut holding the alternator pulley in place loose but don't remove.
5. Relieve the tension on the belt and remove.
6. Remove the (4) bolts bolding the stock crank pulley in place and remove the pulley.
7. Place the race crank pulley in place and use the (4) provided 3/8" socket head cap screws to tighten down.
8. Remove the (4) bolts holding the water pump pulley in place and remove pulley.
9. Put new water pump pulley in place and hand tighten the (4) bolts.
10. Using an impact gun remove the nut holding the alternator pulley in place and remove.
11. Remove the nut holding the alternator pulley in place and remove.
12. Install new alternator pulley and hand tighten the factory nut.
13. Install the new belt on the car.
14. Tighten the (4) water pump bolts and (4) crank pulley bolts evenly.
15. With the impact gun tighten the alternator pulley.