

2005 RADIATOR COVER INSTALLATION

1. Remove plastic pins and two bolts holding stock radiator cover in place.
 2. Remove stock radiator cover.
 3. Place M6 x 20 bolts (the longer of two sizes provided) from bottom up through radiator hold downs (Position A). Secure with lock washer and hex nut. Tighten. Then place two flat washers on bolt over hex nut.
 4. Slide two U clips over horizontal hole on each side of stock grill (Position B).
 5. Slide UPR radiator cover under lip on top of stock grill and lower onto the two M6 x 20 bolts in radiator hold downs. Place washer on bolts and thread on acorn nut. (do not tighten).
 6. Place washers on two M6 x 16 bolts and thread into hole at Position B (do not tighten).
 7. Place washer on two M6 x 16 bolts and thread into Position C.
- NOTE:** Some slight prying or “tweaking” may be needed to start screws.
8. Once all screws are started, tighten evenly. Do not over tighten as radiator cover may distort.
 9. Install hood clip by hooking lower open end through slot with upper hook oriented side to side of car. Once in, turn clip ¼ turn to make upper hook face front.

