



99-04 (1530/1531) Side Scoop Installation

Supplies:

Rubbing alcohol

Rag

Clear Silicone or double sided tape.

Parts:

(1) Passenger Side Scoop

(1) Driver Side Scoop

Estimated Time:

15 minutes.

Directions:

1. Start by lining up each scoop with the correct side so you have it laid out properly.
2. Next clear the area where the scoop will be mounted with rubbing alcohol, Windex can also be used to clear the area.
3. Once the mounting area is clean and dry put a bead of silicone on the back side (side without protective coating on it) of the scoop and press into place. Or you can use double sided tape instead.
4. Hold in place to make sure it stays in place.
5. Then go to the opposite side and repeat.