



## 79-04 Mustang Triple Hook Quadrant & Firewall Adjuster Installation

### Tools needed for UPR Triple pick-up firewall adjuster kit install:

Screwdriver, Pliers, Cutting Pliers, 7mm Nut Driver.

1. Locate stock quadrant & ratchet adjuster mechanism under dash above gas pedal.
2. Remove retaining pin from both shafts. This will allow removal of stock quadrants.
3. Use screwdriver to slide off stock quadrant and ratchet adjuster mechanism.  
**[Note quadrant and ratchet adjuster mechanism still have pressure on them.]**
4. Discard factory spring, quadrant and adjuster mechanism.
5. Install **UPR** Triple pickup quadrant on shaft and re-install both cotter pins.
6. Remove 7mm bolt that retains clutch cable, remove rubber grommet from the firewall side of the cable.

### **Step 7 does not apply to 79–93 Mustangs.**

7. On 94–04 Mustangs you will need to trim the factory plastic that the adjuster sits on for smoother operation. You will also need to cut off the grommet mount.
8. When you are finished installing the **UPR** Triple pick-up firewall adjuster, remember to bolt it back in with the factory screw.
9. Turn the adjuster to the right to loosen (Clutch grabs lower).
10. Turn the adjuster to the left to tighten (Clutch grabs higher).
11. For best adjustment there should be 1 to 1.5" of free play in the clutch pedal.