



## 2005-2007 V6/V8 Throttle Body Spacer

1. Remove factory air inlet hose.
2. Disconnect electrical connectors from the throttle body.
3. **For V6** : Remove the four (4) 8mm throttle body bolts.  
**For V8** : Remove the upper two (2) 8mm bolts, and the lower two (2) 10mm nuts.
4. **For V8** : Remove the lower two (2) studs in the manifold with a pair of pliers or vice grips (be careful not to damage the threads!).
5. Apply a thin layer of silicone around the port opening on the throttle body (this will seal the throttle body to the spacer).
6. Install the throttle body and the spacer onto the manifold using the supplied hardware and washers.
7. Reconnect the electrical connectors.
8. Reconnect the air inlet hose.