

## 2010-2014 Camaro V8 Cold Air Intake Kit



Start by removing the factory intake tube, vent tube and air filter assembly.



Slide the silicone coupler over the throttle body with the 2 4" hose clamps, tighten the back one onto the throttle body and leave the other loose for now.



Remove the factory Mass Air Sensor from your stock air intake and install into the new air intake tube making sure the arrow is pointing towards the throttle body. This is a directional sensor.



Route the provided vent hose to the vent tube on the valve cover and shown. Use the provided clamp on the vent tube to hold it in place.



Insert the rubber grommet into the air intake tube followed by the plastic elbow. This is the connection for the vent hose. Slide the air intake tube onto the coupler for the throttle body and push the vent hose onto the fitting.



Install the stand off onto the air shield as shown with the provided bolt.



Installing the shield make sure the stand off goes into the factory rubber grommet first then line up the second tab with the stud on the other side.



Install the nut over the stud on the back side of the air shield then slide the other 4" clamp over the filter and push the filter onto the intake tube. The rubber neck of the filter should go through opening in the air shield, then tighten down the filter clamp.



Install the weather stripping along the stop of the air shield, plug in the mass air sensor. Go back and tighten the clamps on the throttle body to intake tube. Check all connections and re-install the engine cover.