

10-12 Camaro LS3 6 Speed UPR Oil Catch Can Installation

10-12 Camaro Assembly & Installation Instructions:

1. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and O-ring to hold it in. (Inlet side is the side coming from the valve cover).
2. Screw in the pipe plug or petcock into the bottom of the can.
3. Install the angle mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
4. Install the bottom of the can to the top.
5. Thread the 3/8" elbow fittings into the can making sure that the side towards the front of the car is pointing down and the other side is pointing towards the throttle body.
6. Remove the engine cover if you have one.
7. Just to the left and below the throttle body you will see a hose going from the side of the intake to the engine valley cover this is the crank case to intake vent, remove that hose.
8. In the front of the passenger side cylinder head in the upper left side you will see a stud this is where the long mounting bar will thread onto. Thread the bar into place.
9. Attach the can to the long mounting bar with the hole in the angle bracket as pictured below.
10. Using the provided hose connect the inlet side of the can to the valley cover and the outlet side of the can to the intake (**see picture below**).
11. Double check your connections, level the catch can and tighten the mounting bolt.
12. Re-install the engine cover.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE



Be sure to shop our online store for the best deals: www.uprproducts.com