

2011-2014 F-150 5.0L Oil Catch Can Installation



Install the petcock or plug into the bottom of the can and install both 90° elbows.



Remove the factory vent line by releasing the tab on each end and pull up.



On the lower left side of the radiator locate the flat tab and using the hole on the left mount the catch can to the existing hole.



Route the hoses between the radiator and the plastic shielding and along the battery tray into the engine bay. Connect the inlet side to the valve cover and the outlet side to the intake using the OEM connectors provided. If you have the billet hose ends make sure to install them prior to pushing the hose onto the OEM fittings or catch can fittings.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE