

07-12 Tundra UPR Oil Catch Can Installation

07-12 Tundra Assembly & Installation Instructions:

1. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and O-ring to hold it in. (Inlet side is the side coming from the valve cover).
2. Screw in the pipe plug or petcock into the bottom of the can.
3. Install the bottom of the can to the top.
4. Install the 3/8 fittings into the side of the can.
5. Mount the round catch can bracket to the catch can using the supplied 10/32 socket head screw.
6. Attach the Z bracket to the end of the round catch can bracket with the M10 socket head screw.
7. Mount the catch can in the desired location using the M8 hex bolt.
8. Remove the factory line going from the pcv valve to the intake manifold.
9. Cut the provided hose to size routing the hose from the inlet of the can to the PCV Valve and from the outlet of the can to the intake manifold.

NEVER RETURN OIL FROM THE CATCH CAN BACK INTO THE ENGINE



Be sure to shop our online store for the best deals: www.uprproducts.com