

QA1 A Arm Bushings

The hardware kit with your new A arms includes (2) extra long A arm sleeves and (2) extra A arm washers. If your K-member was made prior to 2013 you will not need these if it's the new style follow the directions below.



Install the long A arm sleeve in both ends of the A arm end tubes. On the front A arm tube make sure the part of the sleeve that sticks out of the bushing is facing the front of the car.

Place an A arm washer on the end as shown.



Install the A arm into the K-member with the A arm spacer facing forward as shown.