

2010 Camaro Automatic L99 Oil Catch Can Installation

1. Install the steel mesh into the inlet chamber side of the top of the can and leave the outlet empty then install the screen and O-ring to hold it in. (Inlet side is the side coming from the valve cover).
2. Screw in the pipe plug or petcock into the bottom of the can.
3. Install the mounting bracket to the oil catch can lid using the supplied Allen head bolt and key.
4. Install the bottom of the can to the top.
5. Install the 3/8 fittings into the side of the can



Remove the two nuts holding the factory airbox in place. Mount the catch can on the factory stud with the airbox mount on top of it. Tighten the two nuts back down.



If you have an engine cover, remove it. Then find the fitting to the left and just behind the throttle body that goes into the intake and disconnect it. Connect the outlet side of the catch can here, route the hose under the throttle body.



The other side of the factory line connects at the back of the driver side valve cover on the top. Disconnect and remove this line. Connect the inlet side of the catch can here.



Reinstall your engine cover if you have it.