

05-14 Mustang Rear Sway Bar Relocation Installation

Directions:

1. Remove the lower shock bolts.
2. Remove the outer sway bar mounts on the axle and bolts and clips from the lower shock mount.
3. Insert a carriage bolt (the one with a square shoulder) into the center hole of the relocation bracket and push that through the back of the top hole on the lower shock mount. Secure with a large flat washer and nylock.
4. Using the lower end of the bracket as a template mark a line where the lower shock mount needs to be cut.
5. Remove the relocation bracket and cut off the bottom of the lower shock mount with a hacksaw, saws-all or cut off wheel and deburr.
6. Reinstall the bracket as described in step 3 and do not tighten.
7. Repeat on other side.
8. Reposition the sway bar mount using the new bolt holes in the relocation bracket and secure with provided hardware and tighten after everything is lined up.

