

# 2015-2017 Ford Mustang Black Mamba Spoiler

## Installation Tips

Thank you for the purchase of the Black Mamba Spoiler for your 2015-2017. Before beginning, please make sure you have the correct spoiler (i.e. Coupe or Convertible). Our Black Mamba spoiler is a custom designed spoiler and DOES NOT utilize Ford's OEM markers/locations. When you locate where you will drill, make sure the drill is held perpendicular to the surface of the trunk. You ONLY drill from outside of vehicle at this point. Drill slowly and make sure to hold the drill perpendicular to the surface the entire time. Because the trunk's inside layer is curved, the drill may be influenced to go in another direction. Drill until you are completely through.



Use the drill locations you just made when you went through the underside of the trunk to locate where you will dremel the opening for the screws. You will need to dremel the bottom section as seen in pictures below for the bolts.

Once the hole is large enough, use the screws provided and screw in your spoiler. Be careful not to overtighten the screws.

If you have any questions, feel free to contact us via email at [sales@bmcextremecustoms.com](mailto:sales@bmcextremecustoms.com),

or call us at 732-970-5272.

