



Bypass for the NEX models

Step 1 ground parking brake wire

Step 2 turn power on push main menu button (bottom center)

Step 3 push AV icon (bottom center)

Step 4 on AV icon screen push off button (towards bottom)

Step 5 touch quadrant 4 (half inch in and half inch up from left lower corner of touch screen) hold your finger there for about 10-12 seconds. "set on" icon will appear that means you are done.

O. W. Donald Co.
5909 Remington Cir.
Fort Smith, AR 72903
479-646-2303
www.owdonald.com