


BCI-3/3e/5/6/8BK ,BCI-3/3e/8PBK
BCI-3/3e/5/6/8C ,BCI-3/3e/5/6/8M
BCI-3/3e/5/6/8Y, BCI-3/3e/5/6/8PC
BCI-3/3e/5/6/8PM

FILLING HOLE PLACE



1. Seal the outlet with the sealing tape and put the cartridge on the tissue paper in case of ink leakage. Make sure the outlet is downward.
2. Make a hold with the screw driver on the cover of the cartridge as the figure show as a filling hole.
3. Assemble the syringe and needle. Insert the needle through the filling hole deeply and then push out for 5-6 ml. Slowly and carefully press the plug of the syringe and fill the ink into the tank until it is full and pull out the syringe.
4. Seal the filling hole with the rubber plug.
5. It may have some ink leak fro the outlet, please clean it with the tissue paper.
6. Reload the cartridge into the printer, and run "head cleaning" utility for 2-3 times before printing or nozzle testing.

Canon BJC-3000/6000/6100/6200/6500;BJ F300; BJF600
Canon S400/S450/S4500/S520/S530D/S600/S750/S6300
Canon i550/i6100/i6500;Canon BJC-8200; BJ F850/F860/
F870 Canon S800/S820/S820D/S830D/S900/S9000Canon
i850;