

# ALEX® PUPPET THEATRE

## ASSEMBLY INSTRUCTIONS

1. The main frame of your puppet theatre comes already assembled. Lower the frame into the triangular shaped base supports by aligning the notches at the bottom of the main frame with the notches in the base supports and fitting them together as shown.

2. Add the center support shelf by aligning the notches in the shelf with the vertical side supports and pushing it down until it rests on top of the chalkboard.

3. Wrap the tabs of the curtain around the curtain rod and secure them with the hook and loop fabric.

4. To assemble the curtain tieback, insert one end of the cord through the large hole in one of the wooden stars. Then tie a knot to secure the star. Insert the loose end of the cord through the hole in the side support of the theatre frame and then through the big hole in the other wooden star. Knot the loose end and repeat step 4 for the other side.

5. Lower the valance onto the top of the theatre frame by aligning it with the slots on top of the side supports.

6. Assemble the clock by inserting the screw and washer through the center of the clock from the back side. From the front attach the washer, clock hands and wooden knob. Tighten the assembly with a screwdriver.

### Preparing the Chalkboard Surfaces:


You will need a piece of chalk and paper towel.

First, holding the piece of chalk horizontally, rub the chalk over the entire chalkboard surface, covering it completely.

Next, take the paper towel and, using a circular motion, rub the towel over the chalkboard surface.

Finally, erase the chalk off the entire surface. You have just seasoned your chalkboard and it is ready for use.

Adult assembly required.



#23K

©2001 ALEX: Northvale, NJ 07647

Visit our website at [www.alextoys.com](http://www.alextoys.com)