

StageHand

A helping hand to lift a folding screen!

This handy little tool will save you time and money on setup. How often do two people go to a job just to handle the folding screens? With the STAGEHAND, you only need one person to set up many popular screens—even those made by our competitors!



1



2

Patent Pending

- 1 Assemble the folding screen face up on floor according to instructions provided. Leave feet folded flat against legs.
- 2 With hook extended “up,” insert the STAGEHAND under top of screen frame and pull back to hold screen frame firmly in place.
- 3 Lift the STAGEHAND and screen, telescoping the STAGEHAND as needed to support screen comfortably. Hook rotates as it lifts.
- 4 The STAGEHAND will support the screen while you unfold and lock the legs in their normal position, following the instructions supplied with the screen.



3

- 5 When finished, set the screen on its feet and pull down firmly to remove the STAGEHAND from top of screen frame. You’ve completed a job for two, all by yourself!

The STAGEHAND comes in two sizes, to fit either 1” folding screen frames (like CINEFOLD) or 1½” frames (like ULTIMATE FOLDING SCREEN). Telescopes from 65” to 120” in length. For use with screens in all sizes through 7’6” x 10’.



5



4