

Wave Series Pump Parts (435/3566)

- 1. Inlet Valve Assembly.....0278251
 - 2. Nylon Seal Washer.....0089482
 - 3. Outlet Seal.....0278362
 - 4. Outlet Seat.....0278280
 - 5. Ball (6mm).....0093635
 - 6. Outlet Spring.....0047485
 - 7. Paint Pump.....0278334
 - 8. Seal.....0156606
 - 9. Washer.....0278340
 - 10. Spring.....0278368
 - 11. Pusher Stem Assembly...0278250
 - 12. Ball Stop.....0278361
 - 13. O-Ring.....9871073
 - 14. Outlet Fitting.....0278335
 - 15. Pusher Body.....0278337
- Prime Spray
Valve.....0278277/0512250

