

Aluminum 2.5" USB 2.0 enclosure cable connection

Plug in primary UBS 2.0 cable connector first to the PC/Notebook for power supply and data transfer. Plug in the extended connector for additional power supply.

Aluminum 2.5" USB 2.0/ Firewire Combo enclosure cable connection

Plug in power cable into one USB port for power supply and then connect the USB cable or Firewire cable for data transfer.

Please note that you can not use USB cable and Firewire cable at the same time and you need to keep power cable connected at all time.