



SONIN[®]

Water Alarm

Reference Guide

Water Alarm with Remote Sensor



Model 10700

SONIN INC.
Phone: 800-223-7511 • Website: www.sonin.com

© 2003 Sonin Inc. All Rights Reserved
Printed in China

FEATURES

- Loud 85 dB buzzer sounds for up to 3 days.
- Intermittent chirp signals low battery.
- Sensor with suction cup may be placed up to 6 feet from the alarm unit.
- Convenient self-test button.

TO ACTIVATE UNIT

1. Remove the 2 screws from back of the larger unit and attach a 9-volt battery (alkaline recommended), being sure to press the clips firmly in place.
2. Reassemble the 2 halves.
3. Press test button and hold for 2 seconds. If the unit is properly assembled, the alarm buzzer will sound.

FOR LEAK DETECTION

Place the sensor (suction cup up) at the lowest point of the floor or other horizontal surface where water collects.

FOR UNATTENDED FILLING OF POOLS, SPAS, ETC.

Use suction cup to attach sensor to smooth vertical surface. Buzzer will sound when water reaches both metal contacts on the sensor.

WARNING

Long term exposure to loud sounds may be harmful to your hearing.

NOTE

Test device periodically by pressing test button on front of unit. Read all instructions carefully and save for future reference.

Warranted against all defects in workmanship and materials for one year from date of original purchase.

TECHNICAL ASSISTANCE

If you have any questions or need technical assistance, e-mail to: technicalsupport@sonin.com

CUSTOMER SERVICE

SONIN takes pride in offering unmatched customer service to owners of SONIN products. If you have any questions or would like additional information, please call: **1 - 800 - 223 - 7511 (USA)**
or e-mail to: customerservice@sonin.com