

## Installation Instructions For Roll-Out Shelves

**IMPORTANT:** In order for shelves to operate properly, drawer bracket and guides must be square.

To square bracket and guides follow this procedure:

1. Remove Roll-Out Shelf from bracket drawer guides. You will need to tilt front of Roll-Out shelf slightly upwards to release the Roll-Out shelf from the guides secured to the bracket.
2. Center front bracket between the cabinet opening. Make sure the front of the guides (A) are one-half inch ( $1/2$  ") behind the face frame. Screw down the front bracket.
3. Measure distance from front bracket side to cabinet wall side – see (B) in drawing – either right or left inside wall of the cabinet. Note distance: \_\_\_\_\_
4. Move back bracket so it is the same distance from inside wall as measurement (B) of front bracket in Step 2.
5. Hold back bracket in place and screw down to shelf. Your bracket is now square.
6. Replace Roll-Out Shelf on bracket drawer guides inside your cabinet. To replace Roll-Out shelf on drawer guides, slightly tilt front of Roll-out upwards and align drawer guide wheels on guide.

**NOTE:** If mounting Roll-Out Shelves to adjustable cabinet shelves, cabinet shelves must first be secured to avoid shelf tipping when Roll-Out Shelf is extended.

