

LELAND® SODA SYPHON

Mr Fizz Senior Classic 1 Liter
Model Number: 11105



IMPORTANT!
READ CARE AND SAFETY
WARNINGS BEFORE USE

SUGGESTION: Charge up your bottle and put it in the refrigerator letting the CO₂ saturate into the water. "It takes cold temperature, gas pressure and a little time to make superior Seltzer." Mr. Fizz

WARNING! High Pressure Device

This pressure carbonation device is designed to be used with a measured amount of water and one 8g CO₂ cartridge. Do not heat. Keep from children. Discontinue use if damaged, leaking or broken.

OVERFILL SLEEVE REMOVAL TOOL →



WARNING!
Only 1 Cartridge per use, do not double charge the device. Too much pressure may cause the relief valve to suddenly open!

MODEL 11105

LELAND®

6 SIMPLE STEPS TO SELTZER

STEP 1 - ASSEMBLE

Push the OVERFILL SLEEVE into the bottle, smooth narrow end first, until top is flush with top of body.

STEP 2 - FILL

Add ice cold water through the center of the OVERFILL SLEEVE until water rises to top. **IMPORTANT:** Never fill without OVERFILL SLEEVE in place! An air pocket must exist over the water level for gas expansion.

STEP 3 - ASSEMBLE

Insert the SYPHON TUBE WITH WASHER into the bottle, through the center of the OVERFILL SLEEVE.

STEP 4 - ASSEMBLE

Screw on the SYPHON HEAD clockwise firmly. **Warning!** Do not remove the SYPHON HEAD unless the gas pressure has been relieved from the BOTTLE.

STEP 5 - GAS CHARGING

Take one 8g CO₂ CARTRIDGE and insert it into the CARTRIDGE HOLDER small end first. Turn the loaded CARTRIDGE HOLDER onto the SYPHON HEAD at the PIERCING AREA. Turn on completely to make a tight seal. **WARNING:** 8g CO₂ Cartridges contain high pressure. Do not heat or store above 140F. Never use more than one CO₂ Cartridge to charge.

STEP 6 - DISPENSING

Dispense into a glass by slowly squeezing the DISPENSING LEVER ARM. **Warning!** Do not attempt to remove the SYPHON HEAD without first releasing ALL the internal pressure from the BOTTLE by first squeezing the LEVER ARM.